



**Dateiname / File name:**  
**543-26-200-375-standard**

Wöhr - Combilift 543-2,6 (Standardtyp)  
Wöhr - Combilift 543-2,6 (Standard type)




**Dateiname / File name:**  
**543-26-200-375-standard-planning**




**Dateiname / File name:**  
**543-26-230-435-premium**

Wöhr - Combilift 543-2,6 (Premiumtyp)  
Wöhr - Combilift 543-2,6 (Premium type)



**Dateiname / File name:**  
543-26-230-435-premium-planning






## CAD-Planungsdarstellung / CAD files: Combilift 543-2,6


**Dateiname / File name:**  
**DS-543\_250\_first**

Combilift 543  
Anfangsraster / First grid  
Plattformbreite 250 / Platform width 250




**Dateiname / File name:**  
**DS-543\_250\_middle**

Combilift 543  
Folgeraster / Middle grid  
Plattformbreite 250 / Platform width 250




**Dateiname / File name:**  
**DS-543\_250\_end**

Combilift 543  
Endraster / End grid  
Plattformbreite 250 / Platform width 250




**Dateiname / File name:**  
**DS-543\_260\_first**

Combilift 543  
Anfangsraster / First grid  
Plattformbreite 260 / Platform width 260




**Dateiname / File name:**  
**DS-543\_260\_middle**

Combilift 543  
Folgeraster / Middle grid  
Plattformbreite 260 / Platform width 260




**Dateiname / File name:**  
**DS-543\_260\_end**

Combilift 543  
Endraster / End grid  
Plattformbreite 260 / Platform width 260




**Dateiname / File name:**  
**DS-543\_270\_first**

Combilift 543  
Anfangsraster / First grid  
Plattformbreite 270 / Platform width 270



**Dateiname / File name:**  
**DS-543\_270\_middle**

Combilift 543  
Folgeraster / Middle grid  
Plattformbreite 270 / Platform width 270



**Dateiname / File name:**  
**DS-543\_270\_end**

Combilift 543  
Endraster / End grid  
Plattformbreite 270 / Platform width 270

